



INSTALLATION INSTRUCTIONS

PART No.

KEN50404

Jeep® CJ5 Wrangler 1955-1983
Rear Body Guard (Pair)



REQUIRED TOOLS

- Drill
- Ratchet
- 1/8" Drill Bit
- 11/32" Drill Bit
- 1/2" Socket
- Hammer
- Center Punch
- Marker

KIT CONTAINS

- Rear Body Guard (Left/Right)
- Carriage Bolt
- Flat Washer
- Lock Washer
- Hex Nut

QTY

- 1 ea
- 6
- 6
- 6
- 6

KEN5040400



INSTALLATION INSTRUCTIONS

PART No.

KEN50404

**Jeep® CJ5 Wrangler 1955-1983
Rear Body Guard (Pair)**

PRE-INSTALL

Align the bottom edge of the guard with the corresponding side of the body tub.

Mark the two mounting holes with a permanent marker.

Remove the part. With a center punch, punch the marks.

Repeat on the opposite side.

DRILL

Using the 1/8" drill bit, drill a pilot hole into the punches.

Using the 11/32" drill bit, re-drill the holes to the required size

Repeat on the opposite side.

INSTALL

Install the Guard with the included (3) bolts, ensuring to use the washers and hex nuts on the interior sides using a 1/2" Socket.

Repeat on the opposite side.

ENJOY YOUR NEW KENTROL REAR BODY GUARDS!

