



INSTALLATION INSTRUCTIONS

PART No. 30497 & 50497

Taillight Guard



Components:

Item	Qty.	Description
A	1	Driver Side Lens Cover
B	1	Passenger Side Lens Cover

Hardware:

Item	Qty	Description
1	6	12 – 24 x 1 ¼” Round Head Screw

**Note: Use anti seize compound on stainless steel hardware
For ease of removal and installation of products.**

Instructions:


1. Remove driver side rear tail lens cover with Phillips screwdriver.
2. Remove and discard three fasteners securing tail lens housing to vehicle body.
3. Feed tail lens wire harness through slotted hole in driver side tail lens cover.
4. Attach light and cover assembly to vehicle using longer bolts supplied.
5. Re-install lens.
6. Repeat steps 1 through 5 for opposite side.



INSTALLATION INSTRUCTIONS

PART No. 30497 & 50497

Taillight Guard



Components:

Item	Qty.	Description
A	1	Driver Side Lens Cover
B	1	Passenger Side Lens Cover

Hardware:

Item	Qty	Description
1	6	12 – 24 x 1 ¼” Round Head Screw

**Note: Use anti seize compound on stainless steel hardware
For ease of removal and installation of products.**

Instructions:

1. Remove driver side rear tail lens cover with Phillips screwdriver.
2. Remove and discard three fasteners securing tail lens housing to vehicle body.
3. Feed tail lens wire harness through slotted hole in driver side tail lens cover.
4. Attach light and cover assembly to vehicle using longer bolts supplied.
5. Re-install lens.
6. Repeat steps 1 through 5 for opposite side.